

3.19 CANALI DMX

5 CANALI

MODE 5 Ch	FUNCTION	DMX Value
1	RED 0~100%	000 - 255
2	GREEN 0~100%	000 - 255
3	BLUE 0~100%	000 - 255
4	WHITE 0~100%	000 - 255
5	Dimmer Speed Mode Preset dimmer speed from display menu Dimmer speed mode off Dimmer speed mode1 (1s) Dimmer speed mode2 (2s) Dimmer speed mode3 (3s) Dimmer speed mode4 (5s) Dimmer speed mode5 (10s) Dimmer speed mode6 (20s)	000 - 010 011 - 045 046 - 080 081 - 115 116 - 150 151 - 185 186 - 220 221 - 255

7 CANALI

MODE 7 Ch	FUNCTION	DMX Value
1	RED 0~100%	000 - 255
2	GREEN 0~100%	000 - 255
3	BLUE 0~100%	000 - 255
4	WHITE 0~100%	000 - 255
5	Dimmer 0~100%	000 - 255
6	Strobe No Function Strobe slow to fast	000 - 010 011 - 255
7	Dimmer Speed Mode Preset dimmer speed from display menu Dimmer speed mode off49 Dimmer speed mode1 (1S) Dimmer speed mode2 (2S) Dimmer speed mode3 (3S) Dimmer speed mode4 (5S) Dimmer speed mode5 (10S) Dimmer speed mode6 (20S)	000 - 010 011 - 045 046 - 080 081 - 115 116 - 150 151 - 185 186 - 220 221 - 255

9 CANALI

MODE 9 Ch	FUNCTION	DMX Value
1	RED 0~100%	000 - 255
2	GREEN 0~100%	000 - 255
3	BLUE 0~100%	000 - 255
4	WHITE 0~100%	000 - 255
5	Strobe No Function Strobe slow to fast	000 - 010 011 - 255
6	RGB/Auto Program No Function Auto program 1 Auto program 2 Auto program 3 Auto program 4 Auto program 5 Auto program 6 Auto program 7 Auto program 8 Auto program 9 Auto program 10 Auto program 11 Auto program 12 Auto program 13	000 - 010 011 - 030 031 - 050 051 - 070 071 - 090 091 - 110 111 - 130 131 - 150 151 - 170 171 - 190 191 - 210 211 - 230 231 - 250 251 - 255
7	Auto speed Auto speed slow to fast	000 - 255
8	Dimmer 0~100%	000 - 255
9	Dimmer Speed Mode Preset dimmer speed from display menù Dimmer speed mode off Dimmer speed mode1 (1s) Dimmer speed mode2 (2s) Dimmer speed mode3 (3s) Dimmer speed mode4 (5s) Dimmer speed mode5 (10s) Dimmer speed mode6 (20s)	000 - 010 011 - 045 046 - 080 081 - 115 116 - 150 151 - 185 186 - 220 221 - 255

49 CANALI

MODE 49 Ch	FUNCTION	DMX Value
1	RED 1 0~100%	000 - 255
2	GREEN 1 0~100%	000 - 255
3	BLUE 1 0~100%	000 - 255
4	WHITE 1 0~100%	000 - 255
5	RED 2 0~100%	000 - 255
6	GREEN 2 0~100%	000 - 255
7	BLUE 2 0~100%	000 - 255
8	WHITE 2 0~100%	000 - 255
....		
41	RED 11 0~100%	000 - 255
42	GREEN 11 0~100%	000 - 255
43	BLUE 11 0~100%	000 - 255
44	WHITE 11 0~100%	000 - 255
45	RED 12 0~100%	000 - 255
46	GREEN 12 0~100%	000 - 255
47	BLUE 12 0~100%	000 - 255
48	WHITE 12 0~100%	000 - 255
49	Dimmer Speed Mode Preset dimmer speed from display menu Dimmer speed mode off49 Dimmer speed mode1 (1S) Dimmer speed mode2 (2S) Dimmer speed mode3 (3S) Dimmer speed mode4 (5S) Dimmer speed mode5 (10S) Dimmer speed mode6 (20S)	000 - 010 011 - 045 046 - 080 081 - 115 116 - 150 151 - 185 186 - 220 221 - 255

51 CANALI

MODE	FUNCTION	DMX Value
51 Ch		
1	RED 1 0~100%	000 - 255
2	GREEN 1 0~100%	000 - 255
3	BLUE 1 0~100%	000 - 255
4	WHITE 1 0~100%	000 - 255
5	RED 2 0~100%	000 - 255
6	GREEN 2 0~100%	000 - 255
7	BLUE 2 0~100%	000 - 255
8	WHITE 2 0~100%	000 - 255
....		
41	RED 11 0~100%	000 - 255
42	GREEN 11 0~100%	000 - 255
43	BLUE 11 0~100%	000 - 255
44	WHITE 11 0~100%	000 - 255
45	RED 12 0~100%	000 - 255
46	GREEN 12 0~100%	000 - 255
47	BLUE 12 0~100%	000 - 255
48	WHITE 12 0~100%	000 - 255
49	Dimmer 0~100%	000 - 255
50	Strobe No Function Strobe slow to fast	000 - 010 011 - 255

51 CANALI

MODE	FUNCTION	DMX Value
51 Ch		
51	Dimmer Speed Mode Preset dimmer speed from display menu Dimmer speed mode off49 Dimmer speed mode1 (1S) Dimmer speed mode2 (2S) Dimmer speed mode3 (3S) Dimmer speed mode4 (5S) Dimmer speed mode5 (10S) Dimmer speed mode6 (20S)	000 - 010 011 - 045 046 - 080 081 - 115 116 - 150 151 - 185 186 - 220 221 - 255

11 CANALI

MODE	FUNCTION	DMX Value
11 Ch		
1	RED 0~100%	000 - 255
2	GREEN 0~100%	000 - 255
3	BLUE 0~100%	000 - 255
4	WHITE 0~100%	000 - 255
5	Dimmer 0~100%	000 - 255
6	Dimmer fine 0~100%	000 - 255
7	Strobe No Function Strobe slow to fast	000 - 010 011 - 255
8	Dimmer Speed Mode Preset dimmer speed from display menu Dimmer speed mode off49 Dimmer speed mode1 (1S) Dimmer speed mode2 (2S) Dimmer speed mode3 (3S) Dimmer speed mode4 (5S) Dimmer speed mode5 (10S) Dimmer speed mode6 (20S)	000 - 010 011 - 045 046 - 080 081 - 115 116 - 150 151 - 185 186 - 220 221 - 255

11 CANALI

MODE	FUNCTION	DMX Value
11 Ch		
9	CCT from - to	
	2800-2900	0-4
	2900-3000	4-7
	3000-3100	7-11
	3100-3200	11-14
	3200-3300	14-18
	3300-3400	18-21
	3400-3500	21-25
	3500-3600	25-28
	3600-3700	28-32
	3700-3800	32-35
	3800-3900	35-39
	3900-4000	39-43
	4000-4100	43-46
	4100-4200	46-50
	4200-4300	50-53
	4300-4400	53-57
	4400-4500	57-60
	4500-4600	60-64
	4600-4700	64-67
	4700-4800	67-71
	4800-4900	71-74
	4900-5000	74-78
	5000-5100	78-81
	5100-5200	81-85
	5200-5300	85-89
	5300-5400	89-92
	5400-5500	92-96
	5500-5600	96-99
	5600-5700	99-103
	5700-5800	103-106
	5800-5900	106-110
	5900-6000	110-113
	6000-6100	113-117
	6100-6200	117-120
	6200-6300	120-124
	6300-6400	124-128
	6400-6500	128-131
	6500-6600	131-135
	6600-6700	135-138
	6700-6800	138-142
	6800-6900	142-145
	6900-7000	145-149
	7000-7100	149-152
	7100-7200	152-156

11 CANALI

MODE	FUNCTION	DMX Value
11 Ch		
9	CCT from - to	
	7200-7300	156-159
	7300-7400	159-163
	7400-7500	163-166
	7500-7600	166-170
	7600-7700	170-174
	7700-7800	174-177
	7800-7900	177-181
	7900-8000	181-184
	8000-8100	184-188
	8100-8200	188-191
	8200-8300	191-195
	8300-8400	195-198
	8400-8500	198-202
	8500-8600	202-205
	8600-8700	205-209
	8700-8800	209-213
	8800-8900	213-216
	8900-9000	216-220
	9000-9100	220-223
	9100-9200	223-227
10	GMP	
	Neutral / No effect	000 - 001
	Full minus green	002 - 003
	-99% (dUV= -0,025) to -1%	004 - 126
	Neutral / No effect	127 - 128
11	1% (dUV= +0,025) to 99%	129 - 253
	Full plus green	254 - 255
	Crossfade from CCT to Color	
	Linear from 0% (CCT) to 100% (Color)	000 - 255