

# DMX CHARTS

| Channel | 5 CH  | 7 CH   | 10 CH        |
|---------|-------|--------|--------------|
| 1       | RED   | DIMMER | DIMMER       |
| 2       | GREEN | RED    | RED          |
| 3       | BLUE  | GREEN  | GREEN        |
| 4       | AMBER | BLUE   | BLUE         |
| 5       | ZOOM  | AMBER  | AMBER        |
| 6       |       | STROBE | COLOR MACROS |
| 7       |       | ZOOM   | STROBE/SPEED |
| 8       |       |        | MODE         |
| 9       |       |        | DIMMER SPEED |
| 10      |       |        | ZOOM         |

| 5 CH | 7 CH | 10 CH | Function                                                                                                                                                                                              | DMX Value                                                                               | Default |
|------|------|-------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------|---------|
|      | 1    | 1     | <b>DIMMER</b><br>0~100%                                                                                                                                                                               | 000 ÷ 255                                                                               | 000     |
| 1    | 2    | 2     | <b>RED</b><br>0~100%                                                                                                                                                                                  | 000 ÷ 255                                                                               | 000     |
| 2    | 3    | 3     | <b>GREEN</b><br>0~100%                                                                                                                                                                                | 000 ÷ 255                                                                               | 000     |
| 3    | 4    | 4     | <b>BLUE</b><br>0~100%                                                                                                                                                                                 | 000 ÷ 255                                                                               | 000     |
| 4    | 5    | 5     | <b>AMBER</b><br>0~100%                                                                                                                                                                                | 000 ÷ 255                                                                               | 000     |
|      |      | 6     | <b>COLOR MACROS</b><br>No Function<br>Color Macros                                                                                                                                                    | 000 ÷ 015<br>016 ÷ 255                                                                  | 000     |
|      | 6    |       | <b>STROBE</b><br>No function<br>Strobe from slow to fast                                                                                                                                              | 000 ÷ 011<br>011 ÷ 255                                                                  | 255     |
|      |      | 7     | <b>STROBE/AUTO SPEED</b><br>No function<br>Strobe from slow to fast<br><b>AUTO SPEED</b><br>Speed slow to fast                                                                                        | 000 ÷ 011<br>011 ÷ 255<br>000 ÷ 255                                                     | 255     |
|      |      | 8     | <b>AUTO MODE</b><br>RGB mode<br>Pulse effect 0-100%<br>Pulse effect 100%-0<br>Pulse effect 100%-0-100%<br>Auto fade transition<br>Auto snap transition (4 colors)<br>Auto snap transition (15 colors) | 000 ÷ 010<br>011 ÷ 050<br>051 ÷ 090<br>091 ÷ 130<br>131 ÷ 170<br>171 ÷ 210<br>211 ÷ 255 | 000     |
|      |      | 9     | <b>DIMMER SPEED</b><br>Present dimmer speed from display menu<br>Dimmer speed mode off<br>Dimmer speed mode 1 (fast speed)<br>Dimmer speed mode 2 (middle speed)<br>Dimmer speed mode 3 (slow speed)  | 000 ÷ 051<br>052 ÷ 101<br>102 ÷ 152<br>153 ÷ 203<br>204 ÷ 255                           | 000     |
| 5    | 7    | 10    | <b>ZOOM</b><br>0~100%                                                                                                                                                                                 | 000 ÷ 255                                                                               | 000     |