

DJ-700

HAZE MACHINE

DJ-700 is deft mini haze machine, easy-to-use. Low fluid consumption, light weight only 6KG. Compact size and high-capacity, with 3Liter fluid tank which can work 11 hours continuously on full output. Whether to be hung or placed on the ground, the angle of haze output can be adjusted freely by internal bracket. 2 knobs to easy control fan speed and output independently. It is suitable for DJ's, smaller venues, bars, and clubs.



Features

- Even and thin haze effect;
- New and fast heater, almost free from clogging;
- Low noise and environmental protection;
- 3 liter fluid tank-12.5 hours on full output;
- Advanced No-Fluid protection;
- Compact size and light weight;
- Water-based fluid, no burnt odor, no harm to the optic;
- Built-in digital display control, manual control, wireless control, and DMX control;
- Please use DJPOWER professional haze fluid PRO-C or PRO-J.

Specifications

AC POWER

- Input Voltage & Rate: 220-240 V, 50/60 Hz
- Current Limiter Type: Fuse (F)
- Current Limiter Specifications: 7A/250V
- Total Power Consumption: 1,200 W
- Operating Current: 5.2 A
- Power Input Connector: IEC

HEATING

- Heat Up Time: Appr. 3.0 min
- Heater Type: Fast Coil Heater

CAPACITY

- Fluid Tank Capacity : 0.8 Gal.

OUTPUT

- Adjustable Volume: ✓
- Volume Adjustment Level/Range: 1-100
- Angle Adjustment Level/Range: 1
- Max Output Volume: Appr. 4,000 cuft/min
- Fluid Consumption @ full volume : Appr. 6.0 mL/min
- Maximum Continuous Duration @ full volume: Unlimited
- Continuous Output : ✓
- Max Continuous Output Level: 100%
- Fully-loaded Cumulative Output Duration @ full volume: Appr. 500 min
- Consumable Type for Standard Output Test: PRO-C/PRO-J

FEATURES

- Physical Thermostat: ✓
- Electronic Thermo-Control: ✓
- Adjustable Output : ✓
- Adjustable Fan Speed: ✓
- No-Fluid Protection: ✓

CONTROL

- On-device Manual Control : 7-seg digital display & Knob(s)
- Wireless Control: W-4 / RF 433MHz / Built-in
- Wired Control: ×
- Control Protocol: DMX-512
- DMX Channel Range: 2
- Data Connectors: 3-pin XLR

ACCESSORY

- Power Cord: ✓
- Wireless Controller Model: W-4 / RF 433MHz / Transmitter
- Wired Controller Model: ×

CONSUMABLE

- Consumable: PRO-C or PRO-J Haze Fluid

WEIGHT & DIMENSIONS

- Net Weight: 6 kg / 13.2 lb.
- Gross Weight: 7 kg / 15.4 lb.
- Machine Dimensions: 395 × 200 × 277 mm / 15.6 × 7.9 × 10.9 in.
- Packing Dimensions: 460 × 315 × 315 mm / 18.1 × 12.4 × 12.4 in.